




구분	관리번호	부품번호	부품명
1	379-2035	3133207001	Decorative Cover
2			
3			
4	379-2036	3133205001	LED Cover
5	379-1002	2831181001	LED Electric Assembly
6	379-1003	2828834001	Front Gear Case Assembly
7	379-2040	5650911001	Small Washer
8	379-2038	5690554001	O Ring
9	379-1137	2851581001	Output Shaft Assembly
10	379-1139	2823193002	Impact Block Assembly
11	379-1005	3570224001	Gear Ring
12	379-1006	2825205001	Rear Gear Case Assembly
13	379-1138	2740638003	Stator
14	379-2045	2751482001	Rotor Assembly
15	379-1008	3121038001	Rubber Stick
16	379-1009	3133639001	Label
17			
18	379-1010	3133088001	F R Button
19	379-1140	2831256002	Main Electric Assembly
20		2851693002	Cover Set
21			
22			
23			
24	379-1015	2828835001	L R Housing Set
25	379-1016	3705756002	Hook
26	379-1017	5620039010	Screw
27	379-1018	5610241004	Screw