




구분	관리번호	부품번호	부품명
1	379-0001	8000001298	Strong Magnetic
2	379-0002	8000001299	Retaining Ring
3	379-0003	8000001300	Gasket
4	379-0004	8000001301	Steel Ball
5	379-0005	8000001302	Shaft Sleeve
6	379-0006	8000001303	Gear Box Shell
7	379-0007	8000001304	The Output Shaft
8	379-0008	8000001305	Shaft Lock Set
9	379-0009	8000001306	Pin
10	379-0010	8000001307	The Ring Gear
11	379-0011	8000001308	Shaft Lock Frame
12	379-0012	8000001309	Planetary Gear
13	379-0013	8000001310	Planetary Gear
14	379-0014	8000001311	Gasket
15	379-0015	8000001312	The Motor Gear
16	379-0016	8000001313	Screw
17	379-0017	8000001314	The Motor Bracket
18	379-0018	8000001315	Motor
19	379-0019	8000001316	Chimney
20	379-0020	8000001317	Push The Button
21	379-0021	8000001318	Switch The Trigger
22	379-0022	8000001319	Spring
23	379-0023	8000001320	PCB Assy
24	379-0024	8000001327	Insulating Paper
25	379-0025	8000001328	Connection Piece I
26	379-0026	8000001329	Connection Piece II
27			The Battery
28			Adhesive Tape
29	379-0027	8000001321	Right Casing
30	379-0028	8000001322	Screw
31	379-0029	8000001323	Screw
32	379-0030	8000001324	Strong Magnetic
33	379-0031	8000001325	Left Casing