




구분	관리번호	부품번호	부품명
1	379-1084	3900455001	L R Housing Set
2	379-1085	2831015001	Electric Assembly
3	379-1086	3901035001	Gear Case Set
4	379-1087	3131209001	Push Button
5	379-1088	3660374001	Torsion Spring
6	379-1089	3705046001	Handle Hoop
7	379-1090	3124287006	Switch Trigger
8	379-1091	3131208001	Dial Button
9			
10			
11	379-1092	2751459002	Rotor Assembly
12			
13	379-1093	2740496002	Stator
14			
15	379-1094	2827321002	Gear Set
16	379-2008	5610241002	Screw
17			
18	379-1016	3705756002	Hook
19	379-1017	5620039010	Screw
20	379-1095	3321181001	Left Rotating Cover
21	379-1096	3131464001	Lock Button
22	379-1097	3704997001	Hoop
23	379-1098	3660497001	Compression Spring
24	379-1099	2827323002	Impact Block Assembly
25			
26			
27	379-4493	5620176001	Screw With Washer
28	379-1100	3131442001	Cover Plate
29	379-1101	3321182001	Right Rotating Cover
30	379-1102	3125847001	Spindle Bush
31			
32	379-1103	5610012004	Tapping Screw
33	379-1104	5690018001	O Ring

구분	관리번호	부품번호	부품명
34	379-1105	5650249001	Washer
35	379-1106	3660516001	Compression Spring
36	379-1107	3553838001	Output Shaft
37	379-1108	3660376001	Spring
38	379-2126	5610225002	Hexagon Lobuar Screw
39	379-1122	3125848001	Support
40	379-1123	2823092003	Top Cover ASSY
41			
42			
43	379-1124	5610004003	Tapping Screw
44	379-1125	4980016001	LED Assembly
45	379-1126	3131190001	LED Cover